

**Parts:**  
MudSling\_LC  
4 Zip Ties

**Tools Required:**  
Pliers  
Wire cutter

**\* BEFORE BEGINNING WORK, READ THESE INSTRUCTIONS FROM START TO FINISH.**

**\* PLACE BIKE ON CENTER STAND ON LEVEL GROUND.**

**\* MUDSLING CAN BE INSTALLED WITHOUT REMOVING THE REAR WHEEL.**



**Care Instructions:**

Clean with soap and water.  
Use Armor-All to restore appearance.



**1** Hold the MudSling next to the bike in the direction of installation.



**2** Place MudSling above rear tire and under the existing fender.



**3** Position the MudSling "shoe" below the existing fender & pull up to engage it. *Shown here with wheel removed.*



**4** *View from right side of bike:* MudSling is shown properly engaged with the end of the fender.



**5** Hold the left side wing of the MudSling against the frame. Insert first zip tie up from the bottom through a slot. *Zip tie head faces the tire.*



**6** Loop the zip tie around the frame and back in through the slot on the outside. Pull zip tie tight. Install second zip tie.

**WARNING AND DISCLAIMER:** All parts manufactured, designed or sold by Machineart Moto ("MaMo") should be installed by a qualified motorcycle technician. The risk of injury is increased by improper installation or misuse of equipment. MaMo's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by MaMo, the responsibility of MaMo is limited to a refund of the purchase price or the replacement of the part if MaMo determines the part to be defective, and subject to MaMo's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to MaMo products will void this limited warranty). MaMo, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever except as provided by law. MaMo makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.



**7** Position the right side wing against the exhaust mount. Install zip ties up from the bottom through the slots, around the frame and in through the outside slots.



**8** After pulling the zip ties as tightly as possible by hand, use pliers to tighten all zip ties fully.



**9** Cut off excess zip tie length with a wire cutter for best appearance.